

SONY

3-754-820-21 (2)

Compact Disc Player

Operating Instructions




CDP-C425

CDP-C325

CDP-C225

Warning

To prevent fire or shock hazard, do not expose the unit to rain or moisture.




This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

For the customers in Australia



This Compact Disc player is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT label is located on the rear exterior.

Owner's Record

The model and serial numbers are located at the rear. Record these numbers in the spaces provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. _____ Serial No. _____

Note on the Transit Key

The transit key on the bottom exterior of the unit protects the optical system against shock during transportation. Before operating the CD player, be sure to remove the key by following the instructions on the label, and store it in a safe place.

When transporting the unit, replace the key in its original hole and lock it in place.

INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

For the customers in Canada

CAUTION:

TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

THIS APPARATUS COMPLIES WITH THE CLASS B LIMITS FOR RADIO NOISE EMISSIONS SET OUT IN RADIO INTERFERENCE REGULATIONS.




Table of Contents

Introduction	3
Precautions	4
Installation	4
Connections	5
Location of controls	6
Front panel	6
Remote commander	7
Installing batteries in the remote commander	7
Playing a disc – Continuous play	8
Information display	9
Selecting a desired disc	10
Locating a particular selection	10
Locating a particular point in a selection	10
Playing in a random order – Shuffle play	11
To play only the desired discs in a random order	
– Select shuffle play	11
Playing in a desired order – Program play	12
Designating the playing time – Program edit	12
Designating the total playing time – Time edit	14
Playing repeatedly – Repeat play	16
Scanning selections – Music scan	16
Tips on editing tapes	17
Fading in/Fading out	17
Fading out after a desired duration – Time fade	17
Locating the loudest portion of the disc	
– Peak search	18
Maintenance	19
Cleaning the cabinet	19
Cleaning discs	19
Specifications	19
Troubleshooting guide	back cover

Introduction

This unit is equipped with 5 disc trays which allow you to choose from a large number and wide variety of selections. Any disc at any time can be played using the DISC 1 to 5 buttons.

Enjoy listening in various playing modes

You can select the playing modes among the following:

- Continuous play (page 8) – The entire disc(s) is played once.
- Shuffle play (page 11) – Selections are played in a random order.
- Program play (page 12) – Selections are played in your desired order.
- Repeat play (page 16) – Single selection or disc(s) are played repeatedly.

Editing your own tapes

- You can fade the play in or out when making your own tape recording. – Fade in/Fade out (page 17)
- You can confirm the total playing time while choosing the selections to be programmed. – Program edit (page 12)
- The player can program selections automatically to fit in a desired duration. – Time edit (page 14)
- You can stop the play, fading out at the time desired. – Time fade (page 17)
- The loudest portion of the disc will be determined and played repeatedly. – Peak search (page 18)

You can play a beginning of each selection

– Music scan

You can check the selections by scanning the beginning of each selection in the disc. You can use this function in any play mode. (page 16)


Easy-to-see display

The selection number, the playing time, the remaining time are displayed by pressing the TIME button. And also playing modes like repeat, shuffle, program are displayed in the display window. (page 9.)

Differences by Model

This instruction manual covers the CDP-C425, the CDP-C325 and the CDP-C225. Their performance and operation are identical except for the following:

	CDP-C425	CDP-C325	CDP-C225
Remote Commander	Supplied	Supplied	Not supplied*
Numeric buttons on the main unit	Provided	Not provided	Not provided

* They do not have those functions activated only by remote commander, which are indicated with  mark in this instruction manual.



This indicates a function operated only on the main unit.

Precautions

On safety

- Check the unit's operating voltage before operation. It must be identical with that of your local power supply.
- Should any liquid or solid object fall into the cabinet. Unplug the unit and have it checked by qualified personnel before operating it any further.
- Unplug the unit from the wall outlet if it will not be used for a long time. To disconnect the cord, pull it out by grasping the plug. Never pull the cord itself.
- As the laser beam used in this compact disc player is harmful to the eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.

On operation

When the unit is not used, turn the power off, to conserve energy and to extend the useful life of your unit.

For the customers in the U.S.A.

For detailed safety precautions, see the leaflet "IMPORTANT SAFEGUARDS".


If you have any questions or problems concerning your unit, please contact you nearest Sony dealer.

Installation

Placing Your Unit

- Place the unit in a location with adequate air circulation to prevent internal heat buildup in the unit.
- Do not place the unit on a soft surface, such as a rug that would block the ventilation holes on the bottom.
- Do not install the unit.
 - near heat sources such as radiators or air ducts.
 - in a place subject to direct sunlight, excessive dust, mechanical vibration or shock.

Not this way.



On moisture condensation


If the unit is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the unit. Should this occur, the player will not operate. In this case, remove the disc and leave the player turned on for about an hour until the moisture evaporates.

Connections

For Correct Connections

- Turn off the power of each unit before making connections.
- Connect the AC power cord last.
- Be sure to insert the plugs firmly into the jacks. Loose connection may cause hum and noise.
- Leave a little slack in the connecting cord to allow for inadvertent shock and vibration.
- Cord plugs and jacks are color coded: Red plugs and jacks are for the right channel (R) and white ones for the left channel (L).


To Connect to an Amplifier




Location of Controls

Front Panel

CDP-C425



CDP-C325/C225




Refer to the pages indicated in () for details.

- | | |
|--|--|
| 1 POWER switch (page 8) | 15 OPEN/CLOSE button (page 8) |
| 2 CONTINUE button (page 8) | 16 PHONE LEVEL (Headphones) control (page 8) |
| 3 SHUFFLE button (page 11) | 17 PHONES (Headphones) jack |
| 4 PROGRAM button (page 12) | 18 CHECK (program check) button (page 13) |
| 5 REPEAT button (page 16) | 19 CLEAR (program clear) button (page 13) |
| 6 Remote sensor | 20 > 10 (OVER 10) button (page 10) |
| 7 Display window | 21 EDIT/TIME FADE button (page 14) |
| 8 TIME button (page 9) | 22 Numeric buttons (1-10) (page 10) |
| 9 ► (play) button (page 8) | 23 FADER button (page 17) |
| 10 ◀◀/▶▶ (AMS*) buttons (page 10) | 24 PEAK SEARCH button (page 18) |
| 11 ◀◀/▶▶ (manual search) buttons (page 10) | 25 MUSIC SCAN button (page 16) |
| 12 ■ (stop) button (page 8) | 26 Disc tray (page 8) |
| 13 ■ (pause) button (page 8) | 27 DISC 1-5 buttons (page 8) |
| 14 DISC SKIP button (page 8) | |

* AMS is the abbreviation of Automatic Music Sensor.

Remote Commander

(CDP-C425/C325 only)




Refer to the pages indicated in () for details.

- 1 PROGRAM button (page 12)
- 2 DISC SKIP button (page 8)
- 3 > 10 (over 10) button (page 10)
- 4 REPEAT button (page 16)
- 5 ■ (stop) button (page 8)
- 6 M.SCAN (Music scan) button (page 16)
- 7 FADER button (page 17)
- 8 ◀◀/▶▶ (manual search) buttons (page 10)
- 9 ◀◀▶▶ (AMS) buttons (page 10)
- 10 ▶ (play) button (page 8)
- 11 || (pause) button (page 8)
- 12 Numeric buttons (1-10) (page 10)
- 13 DISC 1-5 buttons (page 8)
- 14 CONTINUE button (page 8)
- 15 SHUFFLE button (page 11)


Installing Batteries in the Remote Commander

1



2

two size
AA (R6)
batteries



On battery life

- About half a year of normal operation can be expected when using the Sony SUM-3(NS) batteries.
- When the batteries are run down, the remote commander will not operate the unit. In this case, replace both batteries with new ones.


Notes on the remote commander and remote control operation

- Keep the commander away from extremely hot or humid places.
- Avoid dropping any foreign objects into the commander casing, particularly when replacing the batteries.
- Avoid exposing the remote sensor to direct sunlight or lighting apparatus. Such exposure can cause a malfunction.
- To avoid damage caused by battery leakage and corrosion, remove the batteries when the commander will not be used for a long time.



Playing a Disc – Continuous Play

Before playing a disc, turn on the amplifier and set the input selector to the CD player position.

CDP-C425



CDP-C325/C225



To stop play

To stop for a moment during play, press **II**.

Press **▶** or **II** to resume play.

To stop play, press **■**.

To stop play and open the tray, press **▲**.

To start playing from the immediate beginning of a selection.

Press **II** in the stop mode. The unit enters the pause mode at the immediate beginning of the selection.

Press **▶** or **II** to start playing the selection from the immediate beginning. This function is convenient when recording, as it eliminates the seconds prior to the start of selections. You cannot use this function in the program play mode.

Caution on adjusting volume

Do not turn up the volume while listening to a portion with very low level inputs or no audio signals. If you do the speakers may be damaged when a peak level portion is played.

To listen with the headphones


Connect the headphones and control the volume with the PHONE LEVEL control.

Note

The tray number of an empty tray will be displayed until the empty tray number is set to play. Once it is recognized as empty, it will disappear.

Notes on handling discs

- To keep the disc clean, handle the disc by its edge. Do not touch the surface.
- Do not stick paper or tape on the disc.



- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, or leave it in a car parked in direct sunlight as temperature may rise considerably.
- After playing, store the disc in its case.


To play an 8 cm (3-inch) CD

Place it on the inner circle of the tray. If the disc is provided with an adaptor, first remove it. Do not put a normal CD (12 cm/5-inch) on top of an 8 cm CD.

1




2




3

To play more than one disc, place up to 4 more discs in the tray.




4

Choose whether to play one disc (1 DISC) or all discs (ALL DISCS).



Shows that disc is selected to play. When either all the selections on a disc have been played, or the disc is not selected to play, the semi circle is unlit.




Appears under the tray number where the disc currently being played.

Information Display



If you press or the compartment itself to close the compartment, the total number of selections and the total playing time of the disc to be played are displayed for a few seconds.

If you press TIME during stop, you can choose either combination for the display data.



Each time you press TIME during play, the display changes to give you the following information.

- A** Elapsed time in a selection (automatically displayed when play begins)
- B** Remaining time in the selection
"-.-" indication will appear in the display window instead of the actual time, if a selection numbered 21 or higher is selected.
- C** Remaining time of the disc

Notes


- Total remaining time is only available during continuous mode. It will not be displayed by pressing the TIME button during program or shuffle mode.
- Total remaining time will be displayed, if time fade is set during program or shuffle mode.

What is this indication?


no disc

This indication appears when there is no disc at all in the tray.


CDP-C425



CDP-C325/C225



CDP-C425/C325 only



Selecting a Desired Disc

By using the DISC 1 to 5 buttons or the DISC SKIP button during play, you can locate the beginning of any disc.

To select a particular disc	Press the corresponding DISC 1 to 5 button.
To move to the disc tray next to the current one	Press DISC SKIP button.

Locating a Particular Selection

Locating a selection in sequence (Automatic Music Sensor)

You can locate the beginning of a selection on the disc being played.

To locate the beginning of the selection being played	Press ⏮ once.
To locate the beginning of the next selection	Press ⏭ once.

Continue to press until the selection you want is located.

To locate directly

(Except for CDP-C225. For the CDP-C325, this function can be operated with the remote commander only.)

Press one of the numeric buttons (**1** to **10**) to enter the desired selection number.

If a selection number is greater than 10, use the **>10** and **1** to **10** buttons. **10** functions as the figure 0.

e.g. To play from selection No. 22 Press **>10** **2** **2**

To play from selection No. 30 Press **>10** **3** **10**

Locating a Particular Point in a Selection

Locating a point in sequence (Manual Search)

You can locate a particular point during play by monitoring the high-speed sound.

To go back at high speed	Keep ⏮ pressed.
To go ahead at high speed	Keep ⏭ pressed.


Release the button when you reach the point you want.

To locate at higher speed


Press **⏮** or **⏭** in the pause mode. Search speed will increase three times, but there will be no sound. Find the desired point by watching the number in the display.

Playing in a Random Order – Shuffle Play

CDP-C425



CDP-C325/C225



You can have the selections (up to 99) played in a random order. The unit will play all the discs or just one disc you desire.

Once a selection is played, it will not be played again until the random order is completed.

To stop playing

Press ■.

To cancel shuffle play

Press CONTINUE and return to the continuous playing mode.

To change from program or continuous play to shuffle play

Press SHUFFLE during program or continuous play. The program mode will be cleared and shuffle play will begin from the current selection being played.

What is this indication?



This indication appears while the player is "shuffling" the selections.

To Play only the Desired Discs in a Random Order – Select Shuffle Play

Select the desired discs during stop mode (ALL DISCS mode).

To select the desired discs

Press the DISC 1-5 buttons.

A circle will appear around the selected disc number. To choose another disc, press the desired disc number button.


To delete a disc which you have selected, press the DISC 1-5 button for that disc. A circle will disappear around the selected disc number.

To put back all discs which you have deleted, press ■ during stop mode.

Note

During shuffle play in ALL DISCS mode, DISC 1-5, MUSIC SCAN, EDIT/TIME FADE, and PEAK SEARCH buttons do not function.


1




2



Choose whether to play one disc (1 DISC) or all discs (ALL DISCS.)




3




Playing in a Desired Order – Program Play

Up to 32 steps can be programmed in a desired order according to the length of your tape. You can also make a program for both side A and B of the tape at one time.


CDP-C425



CDP-C325/C225



1




2





"PROGRAM" is displayed.

3

Choose the Disc.



If you program a whole disc, see "To program a whole disc".




4

Press selection number in the desired order.*

- For the CDP-C325, this step can be operated with the remote commander only.
- For the CDP-C225, go on to "Designating the Playing Time – Program Edit".



Chosen selections



Current selection

Total playing time


* To choose a selection number over 10, see page 10.

Designating the Playing Time – Program Edit

A Choose selection and check the time.




Press ◀◀/▶▶ repeatedly to choose an appropriate selection.



Current selection

Total time

B A satisfactory selection has been chosen.




The selection is stored, and the flashing numbers in the window light up.

5

To program additional selections from the same disc, repeat step 4.


To program additional selections from another disc, repeat steps 3 and 4.

6 If you program the selections for side B, insert a pause.



A pause is counted as one programming step.

7 Program the selections for side B. Repeat steps 3 to 4.

8  The selections for side A will start playing.

To program a whole disc

- Using the DISC 1 to 5 buttons
After steps 1 and 2:
1 Press the DISC 1 to 5 button to select the disc.
2 Go to step 5.
- Using the DISC SKIP button.
After steps 1 and 2:
1 Press DISC SKIP. "AL" is displayed in the window.
2 Press PROGRAM.
3 Go to step 5.

The whole disc is programmed as one step.

To program while observing the disc labels

You can program the selections with the disc compartment open.

To play the selections for side B

When the selections for side A have been played, the unit will pause. ("B" lights up.)

Set the tape to the beginning of side B, then press ► or ■.

The selections for side B will start playing.

To stop program play

Press ■. The last selection number programmed is displayed.

To resume play, press ►. Play begins from the beginning of the program.

You can play the same program repeatedly as long as you do not cancel program play or erase the program.

To cancel program play

Press CONTINUE and return to the continuous playing mode. The program will be erased.

Skipping to the next selection programmed

Press ►► during play.

Going back to the beginning of the selection being played

Press ◀◀ during play.

To check your program

Press CHECK. The first selection in the program will be displayed when CHECK is pressed during play, the selection being played is displayed.

Each time you press CHECK, the next selection in the program will be displayed. When CHECK is pressed after the last selection, "End" appears and then the display returns to the initial display.

To change your program

You can make the following changes before starting play.

To erase the last selection, press CLEAR during stop mode.

Each time you press CLEAR, the last selection in the program will be erased.

To add a selection to the end of the program, just press the numeric button for that selection. You can add a selection also during play or pause.

To delete a selection, press CHECK repeatedly until the undesired selection is displayed. Then press CLEAR.

To erase the entire program

Press ■ once during stop; twice during play.

The program will be erased in the following situations

- ⏻ is pressed during program play.
- Power is turned off.

To check the step of programmed selections

Press TIME during stop mode.

The number of programmed selections will be displayed for a few seconds in the window.

To check the remaining time

Press TIME once to see the remaining time of the selection being played; twice to return to the initial display.

The total remaining time cannot be displayed.

If you have programmed a selection number over 20, numeric of STEP is displayed instead of the remaining time.


Note

When selections have been programmed for sides A and B, the total playing time displayed during stop mode will show the selections programmed for side B and the total playing time for side B.




Designating the Total Playing Time - Time Edit



CDP-C425




CDP-C325/C225



3 Specify a desired recording time.


a) When you specify a commercially available tape length:

You can designate the tape length easily with the **◀◀/▶▶** buttons. Each time you press a button, the time changes in the following way.




To set the seconds, press **◀◀/▶▶**. The time increases or decreases by 10 seconds.

Example: a 54 minute tape



After 1 second.



b) When you specify a free tape length:



- For the CDP-C325, this step can be operated with the remote commander only.
- This step cannot be operated by the CDP-C225.

Use numeric buttons (1 - 10).

Press 10 for "0".

You need not press keys for seconds, unless required.

Example: a 46 minute tape
(23 minutes per side)




Time

4



The program for side A is completed.
If "LINK" blinks, see "To add selection(s)".

Chosen selections



Last of programmed selection

Total playing time selection

5

Press EDIT/TIME FADE once more, to make a program for the other side of your tape. If "LINK" blinks, see "To add selection(s)".


Note

Total playing time can be set up to 59 minutes 59 seconds.
(For the CDP-C225, total playing time can be set up to 59 minutes 50 seconds.)

You can designate a time and the unit will make 2 different programs of selections each fitting within that period. Use this function, by designating the length of your tape, for editing both sides of a tape.

To add selection(s) — LINK —

After all selections on the disc have been programmed, if there is selection(s) within the remaining time, "LINK" and the selection number(s) will blink.



To add selection, press the numeric button for the selection number (Except for CDP-C225) or press EDIT/TIME FADE again. When pressing EDIT/TIME FADE, a program will be made automatically to fit the playing time as close as possible to the remaining time. If the remaining time can contain other selection(s), "LINK" and the selection number keep blinking. When "LINK" blinks, if the disc is changed by another disc, the new selection number(s) on the new disc that fit in the remaining time will blink.

"EDIT" disappears when the playing time becomes equal to the designated time. Whether "LINK" is blinking or not, you can change the disc by another disc and choose selection(s) to fit the remaining time.

To disappear "EDIT" in the window, press ■.

To play the program

Press ►.

The selections for side A will be played and then the unit will pause. "B" lights up in the tape side indicator. Set the tape to the beginning of side B, then press ► or ■.

The selections for side B will be played.

Note

Playback can be performed when "EDIT" is displayed.

To stop playing

Press ■.

You can play the same program repeatedly as long as you do not cancel time edit or erase the program.

To cancel time edit

Press CONTINUE and return to the continuous playing mode.

The program will be erased.

To erase the entire program

Press ■ once during stop; twice during play.

The program is also erased, when you turn off the unit.

To include desired selections in the program

1 Make your own program of the desired selections.

See page 12 for instructions.

2 Follow the procedure as shown on the preceding page.

Just designate the length of your tape; you need not subtract the length of your program. The unit will place your selections at the beginning of its program and add other selections to fit the remaining time.

To check the program

See page 13.

To designate a different time for each side

Execute steps 1 to 4 and press ■. Then repeat steps 2 and 4.


Do not execute step 5.

If your disc has more than 20 selections


Selections over 20 cannot be programmed with the time edit function; program desired selections before using the time edit function. See page 12 for details.

Playing Repeatedly – Repeat Play

CDP-C425



CDP-C325/C225



Press before or during play.



"REPEAT" appears. The unit repeats the current playing mode.


To repeat a single selection in the continuous play mode, press REPEAT again, "REPEAT 1" appears.

You can repeat a single disc or all the discs.
You can repeat a single selection during continuous play.
You can use repeat play in any play mode.


To cancel repeat play
Press REPEAT again. "REPEAT" disappears.
To cancel repeat play in continuous play mode, press REPEAT until "REPEAT" disappears.

Scanning Selections – Music Scan

CDP-C425



CDP-C325/C225



Press during stop.



► blinks, and each selection plays for approximately 10 seconds and fades out, scanning play starts the next disc or selection.

You can check the selections by scanning the beginning of each selection on the disc. When "ALL DISCS" is selected in the continuous play mode, the first selection of each disc will be scanned.
You can use this function in any play mode.

Starting play at the selection being played during music scan
Press ►.

To stop music scan play
Press ■.

Notes

- Programmed pauses in program mode will be disregarded during music scan play.
- If you press the ◀◀/▶▶ button, music scan will be canceled.
- Pressing the MUSIC SCAN button while the beginning of selection is being scanned will extend the playing time for 10 more seconds.

Tips on Editing Tapes

The following functions are convenient for editing your own tapes.

Fading in/Fading out

You can have the play fade in and fade out between 2-10 seconds.

When no time is specified, the play will fade in and fade out for 5 seconds.

To set the fade time

- 1 Press **■**.
- 2 Press FADER.
- 3 Press **◀◀/▶▶** to select fade time between 2-10 seconds.
- 4 Press FADER again.

To end the play fading out

Press FADER when you want to start fading out.

|||▶ flashes in the window, and play fades out and unit enters the pause mode.

To restart the play fading in

Press FADER in the pause mode.

◀||| flashes in the window, and play fades in.

Fading out after a desired duration – Time Fade



You can have the play fade out at the end by designating the play duration. Once time fade is set, it functions twice for editing both sides of a tape. You can change discs without canceling this function. The fade time is preset to 5 seconds, but you can change it between 2-10 seconds.

To set time fade


- 1 Press EDIT/TIME FADE twice during stop.

TIME FADE is displayed in the window.

- 2 Specify desired fade time.

- a) When you specify a commercially available tape length:

You can designate the tape length easily with the **◀◀/▶▶** buttons. Each time you press a button, the time changes in the following way.



To set the seconds, press **◀◀/▶▶**. The time increases or decreases by 10 seconds.

- b) When you specify a free tape length:
 - For the CDP-C325, this step can be operated with the remote commander only.
 - This step cannot be operated by the CDP-C225.

Use numeric buttons (**[1]**–**[10]**). Press **[10]** for "0". You need not press keys for seconds, unless required.

Example: To set to 27 minutes, press **[2]** **[7]** **[10]** **[10]**.

Note

Total playing time can be set up to 59 minutes 59 seconds.
(For the CDP-C225, total playing time can be set up to 59 minutes 50 seconds.)

- 3 To start play, press **▶**.

After the designated time, play fades out and pauses. Tape side B lights up. Press **|||** or **▶** to resume playing for the other side of the tape. If you press FADER, fade in will start. When the play fades out for the second time, the unit pauses and the time fade function is canceled.

When playback of a disc ended before the designated playing time

The time fade function will remain effective even for a new disc(s) added for the remaining playing time originally designated, and the fade out starts in accordance with the initially set fade time.

To cancel time fade

Time fade will be canceled when

- EDIT/TIME FADE is pressed once again.
- ◀◀/▶▶ (manual search) is pressed during play.

To display the time remaining until the time set

Press TIME twice.

If the PEAK SEARCH is pressed after setting time fade, time fade is released but peak search is kept active.

Locating the Loudest Portion of the Disc – Peak Search



The unit will scan a disc from beginning to end and determine the loudest portion (peak level) of the disc, and then play that portion repeatedly. This function will make it easier for you to adjust to the optimum level when recording on tape. You can use this function in the continuous or shuffle play mode only for a disc which is in play position currently, and in the program play mode for the selections of the entire program.

To set peak search

Press PEAK SEARCH in the stop mode. "PEAK" flashes in the window. The entire tracks in a disc or program will be searched automatically. "PEAK" lights up and the loudest portion will be played repeatedly for 4 seconds. Adjust the recording level on your tape deck according to the peak level.

Note

To go to another disc press DISC SKIP button during stop.

To stop peak search

Press ■.

Press ■■ to pause at the first selection.

To start play immediately

Press ▶.

Note on peak search function

The unit determines the loudest portion (peak level) of a disc by searching it at fixed intervals. As a result, the portion searched may differ from the actual peak level. In addition, this function may determine different portions as the peak level for the same disc. However, the difference between the portion searched and the actual peak level is insignificant and will not present any problem in adjusting the recording level.


Maintenance

Cleaning the CABINET

Clean the cabinet, panel and controls with a soft cloth lightly moistened with mild detergent solution. Do not use any type of abrasive pad scouring powder or solvent such as alcohol or benzine.

Cleaning DISCS

Before playing, clean the disc with the cleaning cloth. Wipe the disc from the center out.



Do not use solvents such as benzene, thinner, commercially available cleaners or anti-static spray intended for analog discs.

After playing, store the disc in its case.

Specifications

System Laser

Compact disc digital audio system
Semiconductor laser ($\lambda = 780 \text{ nm}$)

Laser output

Emission duration: continuous
Max. $44.6 \mu\text{W}^*$

* This output is the value measured at a distance of about 200 mm from the objective lens surface on the Optical Pick-up Block.

Frequency response

2 Hz — 20 kHz ($\pm 0.5 \text{ dB}$)

Signal to noise ratio

More than 100 dB

Dynamic range

More than 98 dB

Harmonic distortion

Less than 0.005% (1 kHz)

Channel separation

More than 100 dB (1 kHz)

Wow and flutter

Below measurable limit

Outputs

LINE OUT (phono jacks)

Output level 2 V (at 50 kilohms)

Load impedance over 10 kilohms

PHONES (stereo phone jack)

Output level 0 — 10 mW (variable) (at 32 ohms)

General

Power requirements

Model for USA and Canada
120 V AC, 60Hz

Model for Australia

240 V AC, 50/60 Hz

Power consumption

12 W

Dimensions

Approx. 430 × 125 × 385 mm (w/h/d) (17 × 5 × 15¼ inches) including projecting parts and controls

Weight

Approx. 5.6 kg (12 lbs 6 oz), net

Remote commander RM-D325 (CDP-C425/C325 only)

Remote control system Infrared control

Power requirements 3 V DC with two batteries size AA (IEC designation R6)

Supplied accessories

Audio signal connecting cord

(phono plug × 2 ↔ phono plug × 2) (1)

Remote commander (1) (CDP-C425/C325 only)

Sony SUM-3 (NS) batteries (2) (CDP-C425/C325 only)

Operating Manual (1)

Design and specifications subject to change without notice.

Troubleshooting Guide

The following checks will assist in the correction of most problems which you may encounter with your unit. Should any problem persist after you have made these checks, consult your nearest Sony service facility. Before going through the check list below, first refer back to the connection and operating procedures.

Trouble	Causes	Remedy
No audio from one or both channels	Incorrect operation of the amplifier	Operate correctly.
	Loose connection	Connect the cords firmly.
Play does not begin.	No disc in the disc compartment	Put disc(s) in the compartment.
	The player is in the pause mode.	Press ► or ■■ to release pause.
	Moisture condensation	Leave the player turned on for about an hour.
	The disc is set upside down.	Set the disc with the label side up.
	The disc is tilted.	Set the disc correctly.
	The disc is extremely dirty.	Clean the disc.
Remote commander does not operate the unit. (For CDP-C425/C325 only)	The batteries are exhausted.	Replace both batteries.
	The remote commander is not pointed at the remote control sensor.	Point the remote commander to the sensor.
	There is an obstacle between the remote commander and the unit.	Remove the obstacle.
	The remote commander is too far from the unit.	Move closer.
Any operation is not possible.	The internal control program may not run.	Turn off the power and turn it on again.